

Laminar Flow

Horizontal Laminar Flow cabinet directs the air through PRE Filter at the bottom level of the cabinet and the airflows horizontally through HEPA filter towards the work area. Again the air is discharged back to the room.

Unit consist of HEPA filter, PRE filter, Blower Assembly, S.S Table Top, U.V Lamp, transparent front door, manometer, Gascock, Side View Glass panel and castor wheel and level jack.

SL.NO	WORKING AREA
1	2' X 2 X 2'
2	3' X 2' X 2'
3	4' X 2' X 2'